



Installation Manual

Faux Beams

Light Weight & Easy to install

1. TOOLS REQUIRED

- 2 X 4
- Power drill
- Construction adhesive
- Saw w/ wood cutting blade
- Trim head screws
- Chalk line
- Small paint brush
- Stud finder
- Tape mark
- Toggle bolts (optional)

2. SPECIAL INSTRUCTIONS & NOTES

- Thoroughly read the installation instructions prior to installation to get familiar with the complete process.
- Before installation, please acclimate the beams to the room for a minimum of 24 hours.
- Beams are not fire rated. Please don't install beams that's close to fire/high heat source.

3. INSTALLATION INSTRUCTIONS

- Measure inside of the beam and cut two by four into blocks to dimension.
- Use stud finder to identify stud location. Mark lines using the chalk line. Use toggle bolts if not able to install onto studs.
- Install precut wood blocks every 3 – 6 feet along the center line. For cathedral ceilings, you might need to stack two blocks to provide the necessary depth for attaching beams.
- Apply marking tapes where wood blocks are installed.
- Dry fit beams to make sure wood blocks will fit inside the beams.
- Apply construction adhesives to the outside of blocks. Install beams and press firmly into place.
- Using trim head screws to fasten beam to blocks. Make sure to countersink screws about a quarter of an inch.
- Clean off excess adhesive and if needed, apply caulk where the beam and ceiling meet. Apply paint for a finished look.

